





Cut the traces in the marked locations (19 places), solder in a 10k resistor between the two circled points at each location.

DIY fixes for v.3.1, 2023-04-13 — In the sequencer, lift leg 15 of the CD4022 and solder two 1n4148 and a 100k resistor to the points shown above.